

Landing gears are operational in flight, on rubber powered models only. Installation is simple and action is positive, if directions are followed carefully. Assemble landing-gear release Tee slide track for main landing gear and nose gear as shown and described in detail note. Cut out center keel L3 between F3 and F5 and at the same time cut off bottom of F4 leav ing sides of F4 intact. Also cut out top rear 1/16 square spar in center section. Make hole and cement evelet in center of both bulkheads F6 and F5, directly above keel. Track (with landing gear release inserted) is now cemente securely to top of center ribs W1, front in line with notch of removed spar. Use two heavy coats on this installation and allow to dry thoroughly making sure release Tee slides freely inside Rear thread is inserted through eyelets pulled snug, and tied securely to rear hook while it is in vertical position as shown. Make sure line is snug, then coat knot with cement. Tie

AND COLOR SCHEME

Wing Span - 32 Ft. 10 In

Length - 25 Ft. 2 In., Height - 6 Ft. 6 1/2 Maximum Speed - 185 M.P.H.

Cruising Speed - 175 M Range - 750 Miles

Engine - Continental

185 H.P. Propeller - 7'6" Dia.

Wing:
Wing Tips:
Fuselage:
Top:
Bottom:

Trim: Port Light: Starboard:

Tail Light:

Grimes Light: Red

Fuel Capacity - 40 Gals

White Yellow Black Red Green

front thread to end of wire cemented in nose re lease block. Pull line up snug and coat knot with cement. Install wheels as described in Final Assembly. This completes mechanism. operate, wind rubber motor. This will pull rear hook forward from a vertical position to a horizontal position, loosening threads, tension released, wheels are then retracted manually (by hand) by bending up into place in wing and slipping strut under 1/32 wire main landing gear retainers, BEING CERTAIN THAT WHEEL AXLES ARE BEHIND LANDING GEAR RELEASE TEE.
Nose gear is bent up in same manner engaged be neath horizontal U cemented to bulkhead F2. Landing gear is now locked in place. As motor unwinds, rear hook pulls back to a vertical position, tightening lines. This pulls main landing gear release Tee which in turn pulls balsa nose release block; moving landing gears past retaining wires. Landing gears now snap down into position for landing.

keel as shown in sketch. This forms a guide hous ing for nose wheel slide. Place slide in housing BEECHCRAFT BONANZA SPECIFICATIONS as shown, inserting wire through horizontal guide previously cemented to bulkhead F2. Installation f system is now completed as described in Operational Landing Gear Installation. Plywood Fire Vall on engine powered models over entire fuselage least back to F5 with /32 or 1/16 sheet balsa. Engine Mount INSTALLATION **ENGINE**

Side View

SLIDE RELEASE DETAIL

Make main landing gear slide release by cutting

strip of plastic (from plastic parts sheet) 1/8

Long U section of Tee shaped wire-landing-gear

and between track covers to form tunnel as shown

release should slide snugly yet freely in tunnel between plastic spacers. Allow to dry thoroughly

Cement a 1/4" length of 1/16 square balsa between

wire on open end of wire-landing-gear release as shown. Allow to dry thoroughly, then trim flush

on top and bottom. Wrap two or three turns of

slide, and tie a 12" length of thread, both to

as described in Operational Landing Gear Instal

supplied in kit). Make nose wheel slide unit by

balsa. Make a right angle bend in straight end

of U shaped wire part and cement in place sand-

two slide retainers from 1/16 balsa to shape

shown. Cement part A vertically against front

cutting two pieces to shape shown from 3/32 scrap

wiched between the two 3/32 balsa blocks as shown

of F2 and part B between part A and center keel L3: both flush with bottom of bulkhead and center

front and rear. Cement assembly into fuse lage

lation. Use good grade of strong thread (not

thread around very end to keep it together, coeting knot with cement. When dry, insert into

two slide track covers 1/16 x 3/8 x 3/4 from

scrap balsa, grain running as shown. Cut a

wide, and cement a double layer to each side

Engine is used if model is being built for control line, free flight or radio. Engine and installation material not provided in kit. Drawing shows installation of Cox .020 Tee Dee engine, however any other similar engine may be used. Cover entire fuselage, at least back to F5 with 1/32 or 1/16 sheet balsa The top is cut out now for engine clearance. Obtain a piece of 1/16 ply wood and cut engine fire wall, using full size drawing, drilling holes indicated. Cut two engine mount blocks 3/16 x 5/16 x 1-3/8 from hard wood. Cement them securely to plywood fire wall in position shown. When dry, drill 1/8 holes through blocks and fire wall. Mount engine to fire wall with #2 nuts and bolts, tightening nuts securely. Cut plastic nut plates from molded sheet and securely cement to back of fire wall

SPINNER

NAVIGATION LIGHTS

over nuts, drilling hole through so that bolts can protrude. Use cement generously. Nut plate keeps nuts from turning so that engine can be removed by just unscrewing bolts. When dry, remove engine. Securely cement fire wall to front of F2. Cut molded engine cowl from plastic sheet as described in detail note and fit over F1. Trim cowl to clear engine. Cowl is not installed until after model is painted, and engine is installed. Cowl is then cemented in place. If it becomes necessary to remove engine for any reason, break cement joint of cowl. Engine is then re-in stalled and cowl re-cemented back in position. Add a 1/2" length of 1/16 I.D. plastic tubing to tubing at angle facing forward for easy admissi

PLASTIC PARTS DETAIL Follow instructions carefully. COWL: Cut from sheet, leaving 1/16 material for trim. Sand and trim off excess material carefully. Cowl may be placed on bulkhead F1 for support while sanding. Clear hole for nose bearing. SPINNER: Carefully sand and trim off excess material in same manner as cowling. Cut out spinner at scribe lines and cement over propeller. GRIMES LIGHT & NAVIGATION LIGHTS: Cut from sheet and trim in same manner, being careful not to lose small parts. NUT PLATES: Cut from sheet right along trim line and install as described in Engine Installation. CABIN: Cut from sheet and trim edges smooth.

Fit in place on fuselage. Install permanently

as described in Final Assembly or hinge as des-

cribed in R/C Note. PAINTING: Regular plastic

model paint or enamel can be used on red parts and clear cabin. Model airplane dope can be used on red plastic only, but must be applied in light spray coat. Excessive use of dope may deform plastic. If red parts are to be painted lighter color, apply a light coat of silver, then white; otherwise lighter color will not take well. This is not required on darker colors. When cementing parts in place on model use light coats of cement applied sparingly. If necessary, use more than one coat, but DO NOT APPLY A THICK COAT AT ANY TIME. Install red Grimes and Navigation lights. See 3-Views for color and location. Installation of other parts are described in text.

NUT PLATES

PLYWOOD ESCAPEMENT BASE Rubber Band 1/8 Holes Antenna Wire - Reciever Moun Torque R BACK-UP PLATES - 2 SE-2 Escapement **ELEVATOR YOKE** Make Two - 1/32 Wire PLYWOOD RECEIVER MOUNT 1/8 Holes UP PLATES -

INSTRUCTIONS

Pattern

CONTROL INSTALLATION

Test models used, and drawing shows, Citizen-Ship MDL Receiver, SE2 Escapement, used with SPX Transmitter. This equipment, and other material necessary, is not provided in kit. Install radio after fuselage frame is completed in Step 4. Stabilizer is cut apart at location shown by dotted lines, then assembled together with cloth hinges, see detail. Bend two wire yokes from 1/32 wire using pattern above, and install on elevators as shown on sketch and full size stab drawing. Mount both with 2/56 nut and bolt Cut escapement base from 1/16 plywood and mount escapement. Cut back-up plates from 1/16 plywood, install blind nuts on rear, then cement to back of bulkhead F5, on each side, in location shown. Install escapement with 2/56 bolts screwed through F5 into blind nuts. Cut recei ver mount and two receiver back-up plates from 1/16 plywood. Cement back-up plates, to front, on either side of bulkhead F3 as shown. ver is installed on mount according to R/C manufacturer's instructions, and unit is in stalled with 2/56 bolts screwed through bulkhead F3 into blind nuts. Remove receiver and escape ment from fuselage and wire radio equipment in accordance with manufacturer's instructions. Line bottom and front of compartment between bulkhead F2 and F3 with foam rubber. Batteries

FLIGHT

When model has been completed, it must balance

7/8 from front of wing at tip ribs W6 as shown

BALANCE HAS BEEN ACHIEVED. Add weight if neces

veloped, remove using steam method described in

Covering Step. Model is now ready for flight.

side view. DO NOT ATTEMPT TO FLY MODEL UNTIL

Check wing and tail. If warps have de-

Pick a calm day for testing. Wind

3/32 Balsa

BALSA NOSE WHEEL SLIDE

with foam rubber. Reciever is then screwed in place as is the escapement. 'Make hole in rear f fuselage at joint formed by side and center keels. Insert a length of 1/16 wire (for torque rod) through hole. Bend U (following R/C manufacturer's instructions and shown above) in front of wire, then pull back and engage in escapement as shown. Make a right angle bend in rear of rod in line with rear of yokes. Solder a length of 1/16 wire to bend making a Tee cross piece, which is engaged in both yokes, extending 1/2" past them when yokes are straight out and elevator is in neutral position. Movement of elevators can be increased by moving yokes away from center and vice versa. Make winding hook and door as described in detail note, then place rubber band between escapement and door hooks. Bend small hook for antenna and cement to front outside corner of right stabilizer. Bring antenna out of fuselage di rectly behind F5 and fasten to hook with rubber Plastic cabin is installed next. Hinge right side of cabin by cementing a length of cloth tape along entire length of cabin and to fuselage. Opposite side is secured by cementing hardwood blocks on inside at front and back lower corners of cabin. Fasten in place with either small wood screws or 2/56 bolts with

make by tightening hook into hand drill.

store winds in motor, stretch rubber out three

to five times original length, then proceed to

finished, it must balance 7/8 back of wing at tip ribs W6, as shown on side view. sary, add weight, but DO NOT ATTEMPT TO FLY UNTIL BALANCE HAS BEEN ACHIEVED. Check wing and tail for warps, if any have developed remove with steam method described in Silkspan Wait for calm weather for test flights. Field test R/C equipment before fly Start engine and THROTTLE DOWN TO LOW then launch model with nose pointed slightly down at a point 50 or 60 feet in front of you and release at approximate flying speed. Model should fly in a straight line and eithe maintain or slightly lose altitude. If model veers to either side, use side thrust with en gine pointed to side opposite of turn to correct situation. Place washers behind proper side of engine to achieve this. Adjustments are also made with elevators as described in Flight Instructions. If model glides well but stalls under power, place washers under top mounting bolts for down thrust. When adjusted properly, your Beechcraft Bonanza should fly in a straight line and maintain or slightly lose altitude at low throttle. Increase engine RPM as adjustments are made, checking R/C controls before each flight. GOOD LUCK AND GOOD FLYING!

blind nuts. When model has been completely

Elevator Yoke

/C Winding

HINGE DETAIL

Use cloth tape for hinges. Cement

only on top and bottom, alternating

out of hinged area between sections

Escapement Rubber

lubricant (available at most hobby shops) or with R.C. WINDING HOOK DOOR Castor Oil. Apply sparingly AND KEEP OFF KNOT OR IT WILL BECOME UNDONE! Use winder which you can Cut out stringer above side keel between F7 and F8 and inset 1/16 balsa flush. Cut out square hole 5/16 x 1/2.
Cement it to a piece 1/16 x 7/16 x 5/8, grain running crosswise to form door. Bend half of hook shown from 1/32 wire TOP and push straight end through door. Bend hook in other end and cement securely to door in position shown. Place loop of rubber between escapeme

CONTROL INSTALLATION

1/2A Bell Crank

Materials required are not provided in kit. Install controls after fuselage Step 4 has been completed. Obtain 1/16 plywood and cut out bell crank platform using drawing provided, drilling hole indicated, then cement it securely in fuse . lage against front of bulkhead F4, resting on side keels L5's. Cut two 15" lengths of lead-outlines and fasten them to 1/2A bell crank. Mount to plywood platform as described in instructions that come with bell crank. Fill in area between F3 and F4, from side keel L5 to stringer above it; with 1/16 balsa, flush with outside of frame Drill two holes through balsa sheet in position shown for lead-out lines. Make special control horn as shown and described in detail note, then cut elevators apart at dotted line shown on draw ing. Hinge together with cloth hinges as shown in detail sketch, then cement control horn securely in place. Tape elevators in neutral position (in line with stabilizer, neither up or Obtain a piece of 1/16 music wire at least 15" long for control rod, and bend 1/4" of one end at right angle. Insert bent end into control horn and solder washer on end to prevent rod from coming off. Insert rod into fuselage through F8, temporarily holding stabilizer in position with pins. Locate and make a right angle bend in front of rod at hole in bell crank for same, with bell crank in neutral position as

PLYWOOD BELL CRANK PLATFORM

1/8 Hole

Bell Crank Platform


shown in sketch. Cut off excess wire, then engage front of control rod in bell crank as shown according to instructions that came with bell crank. Controls are now in neutral position and they should work freely and easily. Stabilizer is now cemented permanently in place, making sure both tips are same height from flat surface Make wing guide from 3/32 balsa, drilling holes indicated. After wing is cemented to fuselage as described in final assembly, securely cement wing guide to top of tip rib W6 as shown, front hole located directly over front 1/16 square wing spar. Reinforce lead-out line holes in fuselage and wing guide with washers or eyelets Thread lead-out lines through holes in fuselage and wing guide, then tie loops in end of lines at least 2" past wing tip. Lines must be of qual length when elevator is in neutral position Control system must operate freely and easily. CAUTION: Model must balance level (or slightly nose down) at point where front leadout line comes out of fuselage. If necessary, add weight. Off-set engine towards outside of circle flown by placing two washers (about 1/32 thick) behind left side of engine. Engine points towards outside of circle flown. Use regular /2A control lines and handle when flying your

Control Horn

CONTROL


WING SPAN 22"

1/16 Control Roc



MODELS U

PHILA., PA. USA



action of retractable landing gear, our model DROPS

LANDING GEAR prior to landing.

